






FOR ELECTRICIAN



ELECTRICAL ROUGH-IN



FROM POWER SOURCE 120V





WARMLY YOURS
MAKING COMFORT EASY

Installation and User Guide

The Installation and User Guide is packaged with the Timer Control. Please open Timer Control package for complete installation and programming information.

Warning

Timer Control can be “on” a maximum of 12 hours in any 24 hour period. However, do not exceed more than 6 hours during any one use.