

# Honeywell



## Deluxe Programmable Thermostat














### Quick Guide

















**T8602D2018 & T8600D2069**



NOTE: Press **Run Program** key at any time to exit programming.

## Set the Current Day and Time









Step	Press	Display
1 Start setting current day and time		
2 Set current day		
3 Set current time	 	
4 Set Daylight Savings Time (DST), if currently DST		
5 Save day and time settings		

## Program the First Day






1 Start programming		
2 Select day		
3 Set period start time	 	
4 Set heating temperature	 	
5 Set period fan operation		
6 Set cooling temperature	  	

Step	Press	Display
7	Program remaining periods (press period key and repeat steps 3 thru 6)	
8	Program remaining days (repeat steps 2 thru 6) or use Copy a Day section	
9	Save program	 


## Copy a Day

1	Start copying	 
2	Store program to copy	 
3	Select day to copy program to	 
4	Copy to day	 

## Make Temporary Changes

1	Change current period temperature	  
2	Change current period fan setting	 

## Set Hold

1	Set indefinite Hold <ul style="list-style-type: none"> <li>Select Hold temperature</li> </ul>	   
---	---	--

Step	Press	Display
<p><b>2</b> Set Hold for vacation (up to 256 days)</p> <ul style="list-style-type: none"> <li>Set number of days</li> <li>Select period to end Hold</li> <li>Select Hold temperature</li> </ul>	<p>Hold Temp</p> <p>(twice)</p> <p>Time</p> <p>▲</p> <p>▼</p> <p>Return</p> <p>▲</p> <p>▼</p>	<p>Hold for 1 Days</p> <p>Wake</p> <p>Hold for 18 Days</p> <p>Wake</p> <p>Hold for 18 Days</p> <p>Return</p> <p>Setting 54°</p> <p>System Heat</p> <p>Fan</p> <p>Heat</p> <p>Auto</p>
<p><b>3</b> Return to program</p>	<p>Run Program</p>	<p>8:15 AM</p> <p>Tue</p> <p>Wake</p> <p>68°</p> <p>Room</p> <p>DST</p> <p>System Heat</p> <p>Fan</p> <p>Auto</p>

## View or Rest Filter Timer Settings

<p><b>1</b> Check "Filter" Timer status</p>	<p>i</p> <p>(three or four times)</p>	<p>Filter</p> <p>0 A 15</p> <p>Days</p>
<p><b>2</b> Reset Timer</p>	<p>Time</p> <p>▲</p> <p>▼</p>	<p>Filter</p> <p>30 A 15</p> <p>Days</p>